



415 Pembroke Circle, Alpharetta, GA 30004

770-693-2613

Installation Guidelines

Packaging – check your product for all parts.



Outdoor shower Installation (60003 and 60009)

Step one - Verify supply lines should be 6 inches (+/- ½ inch) apart and a minimum of 24 inches from the ground.

Step two – Attach female threaded adaptor to the supply line (not included). Thread size (1/2 - 12)

Step Three - Thread adaptor onto the supply lines (smallest side)



Cross threading will cause leaking plumbers dope may be used

Step four – Attach riser to the valve body



Use Teflon tape or silicone on threads.

Step five – On the back of the valve body, locate nuts and position adaptor from the supply line. Start threading by hand and tighten using a spanner wrench. (Spacers are provided)



Use Teflon tape on threads

Step six – Locate wall bracket for riser. Mark your location on the wall and attach wall bracket. Secure escutcheon. Insert mounting pipe into mounting bracket and clip into place



Step seven – thread shower head to the riser.



Use Teflon tape on threads and hand tighten snug with spanner wrench.

**TURN ON SUPPLY LINES AND TEST YOUR CONNECTIONS FOR
LEAKS.....**

Enjoy your new outdoor shower!

